



AINA Vehicle Charger

The AINA Vehicle Charger is a charging cradle specially designed for AINA PTT Voice Responder users who are looking for a safe and simple way of using their Bluetooth speaker mic while driving.

KEY BENEFITS

DESIGN

Designed for the use in light, medium or heavy duty trucks and construction vehicles, the AINA Vehicle Charger provides a safe and user friendly location for the AINA Voice Responder.

- Simulates the same movement to take out and put back the mic that drivers are used to from old CB radio mics
- Keeps the Voice Responder stable even during heavy vibrations
- Lanyard provides additional safety to recover device when dropped

COMPATIBILITY

Compatible with all major mount manufacturers, the AINA Vehicle Charger can easily be installed alongside any tablet or mobile phone holder.

- Use integrated solutions provided by major mount manufacturers
- Use splitter bars to extend your existing tablet mount
- Install directly to the dash
- Use any standard AMPs hole pattern or male ¼"-20 threaded steel stud
- Connected through a standard 5V male USB connector

SOLVING CUSTOMER PROBLEMS

Q: Where do I put my Bluetooth Remote Speaker Mic (RSM) while driving?

A: Place the vehicle charger cradle in a location where you can pick it up without bending or changing your driving position to be compliant with driving regulations.

Q: How can I make sure my RSM is always charged?

A: Don't worry about needing to charge your RSM anymore! It's being charged continuously as soon as you place it into the cradle and will still transmit any incoming communication while charging.

Q: Don't RSM micro-USB ports break over time?

A: Through the charging contacts on the back of the AINA Voice Responder, the micro-USB port is not used anymore which reduces device failure rates significantly.